## TRI GLIDE ULTRA PRELOAD CHART

### Additional Weight of PASSENGER, CARGO, AND ACCESSORIES (Lbs)

	0	40	80	120	160	200	240	280	320	360	400	
100	11/16"	13/16"	15/16"	1 1/16"	1 3/16"	1 5/16"	1 3/8"	1 1/2"	1 5/8"	1 3/4"	1 7/8"	
120	3/4"	7/8"	1"	1 1/8"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 11/16"	1 13/16"	1 15/16"	
140	13/16"	7/8"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 5/8"	1 3/4"	1 13/16"		
160	13/16"	15/16"	1 1/16"	1 3/16"	1 5/16"	1 7/16""	1 9/16"	1 5/8"	1 3/4"	1 7/8"		
180	7/8"	1"	1 1/8"	1 1/4"	1 5/16"	1 7/16""	1 9/16"	1 11/16"	1 13/16"			
200	15/16"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 5/8"	1 3/4"	1 7/8"	T.		
220	15/16"	1 1/16"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 11/16"	1 3/4"				
240	1"	1 1/8"	1 1/4"	1 3/8"	1 7/16"	1 9/16"	1 11/16"	1 13/16"		SVET TO	7	
260	1 1/16"	1 3/16"	1 1/4"	1 3/8"	1 1/2"	1 5/8"	1 3/4"		-		•	
280	1 1/16"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 11/16"	1 13/16"					
300	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 9/16"	1 11/16"		_				
320	1 3/16"	1 5/16"	1 3/8"	1 1/2"	1 5/8"	1 3/4"						
340	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 11/16"				Increase Spring			
360	1 1/4"	1 3/8"	1 1/2"	1 5/8"	1 3/4"	Preload						
380	1 5/16"	1 7/16"	1 1/2"	1 5/8"		REFER TO THE CHART ABOVE TO DETERMINE THE CORRECT PRELOAD MEASUREMENT						
400	1 5/16"	1 7/16"	1 9/16"	1 11/16"		BASED ON THE RIDER WEIGHT, PLUS THE ADDITIONAL WEIGHT OF THE PASSENGER, CARGO, AND ACCESSORIES.						
420	1 3/8"	1 1/2"	1 5/8"		•	CAROO, AND A	ACCESSORIES.				Reduce	
440	1 7/16"	1 9/16"	1 5/8"				MEASURE:				Spring Preload	
460	1 7/16"	1 9/16"		EXAMPLE: RIDER WEIGHT: 200 LBS PASSENGER/CARGO/ACCESSORY WEIGHT: 160 LBS TARGET MEASUREMENT: 1 3/8"  FROM THE BASE OF THE THREADED SPRING SEAT  TO THE FLAT SURFACE ON THE LOWER LOOP								
480	1 1/2"	1 5/8"										
500	1 9/16"											
520	1 9/16"											

## CHART 1

\*Legend Suspension shocks are not intended to increase the vehicle's GVWR (Gross Vehicle Weight Rating)

\*\* Refer to your Harley-Davidson Owners Manual for the maximum additional weight your vehicle can safely carry

# FREE WHEELER / ROAD GLIDE 3 PRELOAD CHART

### Additional Weight of PASSENGER, CARGO, AND ACCESSORIES (Lbs)

	0	40	80	120	160	200	240	280	320	360	400	
100	1/2"	5/8"	3/4"	7/8"	1"	1 1/8"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 11/16"	
120	9/16"	11/16"	13/16"	15/16"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 5/8"	1 3/4"	
140	5/8"	11/16"	13/16"	15/16"	1 1/16"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 5/8"		
160	5/8"	3/4"	7/8"	1"	1 1/8"	1 1/4"	1 3/8"	1 7/16"	1 9/16"	1 11/16"		
180	11/16"	13/16"	15/16"	1 1/16"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 5/8"	2		
200	3/4"	13/16"	15/16"	1 1/16"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	1 11/16"	T.		
220	3/4"	7/8"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 9/16"				
240	13/16"	15/16"	1 1/16"	1 3/16"	1 1/4"	1 3/8"	1 1/2"	1 5/8"		27	<b>5</b>	
260	7/8"	1"	1 1/16"	1 3/16"	1 5/16"	1 7/16"	1 9/16"					
280	7/8"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	1 5/8"					
300	15/16"	1 1/16"	1 3/16"	1 5/16"	1 3/8"	1 1/2"						
320	1"	1 1/8"	1 3/16"	1 5/16"	1 7/16"	1 9/16"						
340	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"				Increase Spring			
360	1 1/16"	1 3/16"	1 5/16"	1 7/16"	1 9/16"	Preload						
380	1 1/8"	1 1/4"	1 5/16"	1 7/16"		REFER TO THE CHART ABOVE TO DETERMINE THE CORRECT PRELOAD MEASUREMENT BASED ON THE RIDER WEIGHT, PLUS THE ADDITIONAL WEIGHT OF THE PASSENGER, CARGO, AND ACCESSORIES.						
400	1 1/8"	1 1/4"	1 3/8"	1 1/2"								
420	1 3/16"	1 5/16"	1 7/16"			CARGO, AND A	CCL33ORIL3.				Reduce	
440	1 1/4"	1 3/8"	1 7/16"				MEASURE:				Spring Preload	
460	1 1/4"	1 3/8"		EXAMPLE: RIDER WEIGHT: 160 LBS PASSENGER/CARGO/ACCESSORY WEIGHT: 120 LBS TARGET MEASUREMENT: 1" TO THE FLAT SURFACE ON THE LOWER LOOP								
480	1 5/16"	1 7/16"										
500	1 3/8"											
520	1 3/8"											

## **CHART 2**

\*Legend Suspension shocks are not intended to increase the vehicle's GVWR (Gross Vehicle Weight Rating)

<sup>\*\*</sup> Refer to your Harley-Davidson Owners Manual for the maximum additional weight your vehicle can safely carry